

OIL TANK CAP SAFETY ADAPTER

P/N PT8611A01

COMPONENT MAINTENANCE MANUAL WITH ILLUSTRATED PARTS LIST

NOTE: This oil tank cap safety adapter is used on aircraft equipped with Pratt & Whitney JT8D-1, -1A, -1B, -7, -7A, -7B, -9, -9A, -11, -15, -15A, -17, -17A, -17R, -17AR, -209, -217, -217A, -217C and -219 engines.

79-20-03
TITLE PAGE
MAY 25/94

()

()

()

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

RECORD OF REVISIONS

REV NO	REV DATE	DATE FILED	BY	REV NO	REV DATE	DATE FILED	BY
Orig	5/25/94						

**PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01**

INTENTIONALLY LEFT BLANK

**79-20-03
PAGE 2
MAY 25, 1994**

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

RECORD OF TEMPORARY REVISIONS

REV NO.	T/R DATE	DATE FILED	BY	DATE REMOVED	BY	INCRP IN REV. NO

**PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01**

INTENTIONALLY LEFT BLANK

**79-20-03
PAGE 4
MAY 25, 1994**

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

SERVICE BULLETIN LIST

SERVICE BULLETIN NO.	DATE INCORPORATED	REV INCORPORATED	SUBJECT
SB# 8611-79-1	April 25, 1990		Installation Clearance

**PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01**

INTENTIONALLY LEFT BLANK

**79-20-03
PAGE 6
MAY 25, 1994**

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

LIST OF EFFECTIVE PAGES

<u>CHAPTER/ SUBJECT</u>	<u>PAGE</u>	<u>DATE</u>
Title Page	-	May 25/94
Record of Revisions	1	May 25/94
	2	Blank
Record of Temporary Revisions	3	May 25/94
	4	Blank
Service Bulletin List	5	May 25/94
	6	Blank
List of Effective Pages	7	May 25/94
	8	Blank
Table of Contents	9	May 25/94
	10	May 25/94
Introduction	11	May 25/94
	12	Blank
Description and Operation	13	May 25/94
	14	May 25/94
Testing	15	May 25/94
	16	May 25/94
	17	May 25/94
	18	Blank
Disassembly	19	May 25/94
	20	May 25/94
Cleaning	21	May 25/94
	22	Blank
Check	23	May 25/94
	24	Blank
Repair	25	May 25/94
	26	May 25/94
Assembly (Including Storage)	27	May 25/94
	28	May 25/94
	29	May 25/94
	30	Blank
Special Tools Fixtures and Equipment	31	May 25/94
	32	Blank
Illustrated Parts List	33	May 25/94
	34	May 25/94
	35	May 25/94
	36	May 25/94
	37	May 25/94
	38	Blank

**PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01**

INTENTIONALLY LEFT BLANK

**79-20-03
PAGE 8
MAY 25, 1994**

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

TABLE OF CONTENTS

DESCRIPTION AND OPERATION

<u>Description</u>	13
<u>Operation</u>	13

TESTING

<u>Test Equipment and Materials</u>	15
Equipment		
Materials		
<u>Test Procedures</u>	15
Flapper Leak Check		
Oil Cap Leak Check		

DISASSEMBLY

<u>General</u>	19
<u>Disassembly Procedure</u>	19

CLEANING

<u>Cleaning Agents/Materials</u>	21
<u>Cleaning Procedures</u>	21

CHECK

<u>Check Procedure</u>	23
------------------------	---------	----

REPAIR

<u>Repair No. 1 - Repair of Surface Corrosion or Wear</u>		25
---	--	----

PTM INTERNATIONAL, INC.
 COMPONENT MAINTENANCE MANUAL
 PT8611A01

TABLE OF CONTENTS

<u>Repair No. 2 - Replacement of Flapper, Hinge Assembly or Pin</u>	25
<u>Repair No. 3 - Replacement of Plunger Shaft O-Ring</u>	25
<u>ASSEMBLY (INCLUDING STORAGE)</u>	
<u>Special Tools, Equipment and Materials</u>	27
<u>General</u>	27
<u>Assembly Procedure</u>	27
<u>Storage After Assembly</u>	29
<u>SPECIAL TOOLS, FIXTURES AND EQUIPMENT</u>	31
<u>ILLUSTRATED PARTS LIST</u>	
<u>INTRODUCTION</u>	
<u>Purpose</u>	33
<u>Explanation and Usage of Section</u>	33
Effectivity Code Column	
Quantity per Assembly Column	
Service Bulletin Incorporation	
<u>Vendor Code List</u>	36

ILLUSTRATIONS

	Fig.
Sectional View of Oil Tank Cap Safety Adapter	1
Test Setup	2
IPL -- Oil Tank Cap Safety Adapter	1

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

INTRODUCTION

This component Maintenance Manual fully describes the oil tank cap safety adapter assembly and the applicable procedures for testing, disassembly, renewal and repair, and reassembly. The technical staff at PTM International, Inc. will be pleased to advise on any questions regarding maintenance of the unit.

**PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01**

INTENTIONALLY LEFT BLANK

**79-20-03
PAGE 12
MAY 25, 1994**

OIL FILLER AND VALVE

DESCRIPTION AND OPERATION


1. Description

- A. The oil tank cap safety adapter prevents loss of engine oil when filler caps are improperly installed, are damaged, or are entirely missing. The unit is installed in the engine oil tank in place of the current filler cap, P/N 478843. No modifications of the engine are required; the unit is simply installed in the same manner as the cap and locked in place by a special locking mechanism. The original oil filler cap is inserted into the unit and locked in place in the usual manner.
- B. The unit is designed as a check valve formed by a gravity-actuated hinged flapper that seals against a flat-faced Viton rubber gasket which surrounds the oil fill passage. The flapper pivots on a wear resistant pin and is retained in a clevis on the stainless steel sleeve by welds at both ends of the pin. The gasket has a T-shaped cross section and fits into a groove machined into the body with a matching T-shaped cross section.

2. Operation

- A. Oil servicing of the engine is accomplished by removing the oil filler cap and adding oil as required. The flapper will open when oil is poured into the filler; however it will normally remain closed by the action of gravity. In instances when oil system pressure may not be totally relieved, the flapper may need an assist in opening by pushing against it with a screw driver or other suitable device.
- B. In instances when the oil cap is damaged or missing, the oil system pressure retains the flapper against the gasket. This provides a positive seal in any flight attitude, even when the flapper is not subject to gravity-aided closure.

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01



Sectional View of Oil Tank Cap Safety Adapter
Figure 1

TESTING

1. Test Equipment and Materials

A. Equipment

- (1) Pressure test vessel. PTC P/N 91PT155.
- (2) Pressure gage 0-30 psi.
- (3) Oil cap. PWC P/N 478843.
- (4) Pressure regulator.
- (5) Copper tubing.
- (6) O-ring. MS9388-331.

B. Materials

- (1) Turbine oil. Mobil Jet 254 or equivalent. One quart.

2. Test Procedure

A. Flapper leak check (cap not installed)

- (1) Install MS9388-331 O-ring on unit.
- (2) Coat gasket and O-ring with Mobil Jet 254.
- (3) Assemble unit into 91PT155 pressure vessel of test rig without oil cap installed.
- (4) Add Mobil Jet 254 or equivalent through filler neck to level at least 1/4" above top of flapper. Tilt unit to close flapper. Apply 5 to 10 psig air pressure to hold flapper closed.
- (5) Remove any oil from above flapper using syringe and/or absorbent material.
- (6) Lower pressure to 2.5 psig.
- (7) Inspect for oil leaks through flapper. Limit is 1.0 cc per minute.


PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

- (8) Reduce pressure to zero.
- (9) Open flapper using suitable device such as a 1/8" diameter 6-inch long rod and validate that oil level covered flapper.
- (10) Remove unit from test rig.
- (11) Remove MS9388-331 O-ring.

B. Oil cap leak check.

- (1) Install MS9388-331 O-ring on unit.
- (2) Coat O-ring with Mobil Jet 254.
- (3) Insert device to prevent flapper closure.
(suggest 1/16 diameter piece of wire positioned to hold flapper open while not interfering with cap).
- (4) Install oil cap O-ring, if required (oil cap 478843). Coat O-ring with Mobil Jet 254.
- (5) Install oil cap in oil filler unit.
- (6) Assemble unit into 91PT155 pressure test rig.
- (7) Immerse vessel in water bath. Assure water totally covers oil filler unit.
- (8) Apply air pressure of 10 psig.
- (9) Inspect for leaks, indicated by bubbles.
None permitted for one minute hold.
- (10) Reduce pressure to zero.
- (11) Remove unit from water bath..
- (12) Remove cap.
- (13) Remove flapper disabling device.
- (14) Remove MS9388-331 O-ring.

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01



Test Setup
Figure 2

**PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01**

INTENTIONALLY LEFT BLANK

79-20-03
PAGE 18
MAY 25, 1994

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

DISASSEMBLY

1. General

- A. The procedure to totally disassemble the unit is described below. Disassembly should only be conducted to the level necessary to correct test or check discrepancies or to comply with the user's component maintenance program.
- B. Refer to the IPL for item numbers quoted in the following instructions.

2. Disassembly Procedure

- A. Remove O-ring (10).

CAUTION: BE CAREFUL NOT TO DAMAGE RETENTION GROOVE IN REMOVING GASKET.

- B. Remove gasket (20) by carefully prying out of its retention groove using a pointed tool. Discard removed gasket.

- C. Flapper hinge assembly (40) removal from body (130):

CAUTION: WHEN REMOVING RETENTION WELDS, REMOVE MINIMUM MATERIAL. DO NOT REDUCE CLEVIS WIDTH EXCEPT SPECIFICALLY AT TACK WELD LOCATIONS.

- 1. Mill pin retention tack welds to .005 to .010 below surface on both sides of hinge clevis.
- 2. Drift out pin (30) using 1/16 diameter punch.
- 3. Remove flapper hinge assembly (40).

- D. Lock Assembly Removal

- 1. Remove screw (50) and lock clip (60).
- 2. Remove tack weld retaining socket-head screw (70) to block (80) and remove screw and block.
- 3. Push plunger (90) and pin (110) through body being careful to catch compression springs (100).

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

4. Remove two compression springs (100) if they did not fall out during removal of plunger.
5. Remove pin (110) from plunger.
6. Remove O-ring (120) from plunger and discard.

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

CLEANING

1. Cleaning Agents

Stoddard Solvent mineral spirits. (Federal specification P-D-680) or equivalent.

2. Cleaning Procedure

Note: The unit may be cleaned in the assembled condition or disassembled.

Thoroughly clean all components in Stoddard Solvent mineral spirits.

**PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01**

INTENTIONALLY LEFT BLANK

**79-20-03
PAGE 22
MAY 25, 1994**

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

CHECK

1. Check Procedure

- A. Visually check the body (130) screw (50), block (80) and plunger (90) for damage. In particular the spherical end of the screw and the tapered end of the plunger must be free of nicks and burrs. Minor external damage may be treated as detailed in Repair No. 1.
- B. Examine gasket for cuts or scores. Replace damaged gasket.
- C. Examine flapper sealing face for scores and scratch damage. Replace damaged flappers as detailed in Repair No. 2.
- D. Examine plunger O-ring (120) for cuts or scores. Replace damaged O-ring as detailed in Assembly.
- E. Determine degree of hinge pin wear as follows: Place flapper in closed position against gasket. Push and pull flapper toward and away from retaining lug. If movement is in excess of .035 in. the pin should be replaced by procedure noted in Repair No. 2.
- F. Check flapper to gasket sealing contact in a darkened room by shining a flash light parallel to the gasket/flapper interface. Replace distorted flappers as detailed in Repair No. 2.

**PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01**

INTENTIONALLY LEFT BLANK

79-20-03
PAGE 24
MAY 25, 1994

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

REPAIR

I. Repair No. 1 - Repair of Minor Surface Corrosion or Wear

A. Materials

Grade 240 emery cloth.

B. Repair Procedure

1. Polish out slight external damage with grade 400 or finer emery cloth.

II. Repair No. 2 - Replacement of Flapper or Pin

A. Materials

18-8 SS Weld wire.

B. Repair Procedure

1. Remove flapper and pin as noted in Disassembly.
2. Remove gasket as noted in Disassembly and discard.

NOTE: Gasket must be removed, regardless of its condition. If it is not removed it will be damaged by the welding heat used for pin retention.

3. Install new flapper or new pin as noted in Assembly.
4. Install new gasket as noted in Assembly.

III. Repair No. 3 - REPLACEMENT OF PLUNGER O-RING

A. Materials:

None.

B. Repair Procedure:

1. Remove damaged O-ring.
2. Install new MS9388-006 O-ring on plunger shaft.

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

B. Repair Procedure: continued

3. Measure diameter of mating hole in body.
(Reference .220 dia.)
4. Grind outside diameter of O-ring, while mounted on shaft, to provide a slip fit in the mating hole.

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

ASSEMBLY (INCLUDING STORAGE)

1. Special Tools, Equipment and Material

<u>Item No.</u>	<u>Description</u>	<u>Remarks</u>
1.	ETO-25	For lubricating gasket and O-ring before installation.
2.	Test rig	For testing unit.
3.	Oil Cap	For testing unit.
4.	O-ring	For testing unit.

2. General

A. Refer to Fig. 3 for the item numbers quoted in the following assembly procedure.

3. Assembly Procedure

A. Installing new flapper or new pin on sleeve.

- (1) Clean the outside faces of the clevis on the flapper hinge assembly (40) where the pin retention weld will be made. Use 400 grit emery cloth or equivalent.
- (2) Position flapper, hinge assembly (40) clevis to dovetail with lug on body (130).
- (3) Insert pin (30) through hinge clevis and body lug holes. Position pin to be centered in clevis.
- (4) Apply approximate 1/32 in. weld bead at both ends of hinge pin hole on clevis outside faces. Use gas tungsten arc per welding using 18-8 SS weld filler.

B. Installing Gasket in Body

- (1) Coat gasket (20) and sleeve retention groove with ETO-25 or equivalent.
- (2) Align gasket (20) over retention groove.

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

- (3) Press ID of gasket (20) into groove by hand. Avoid force in circumferential direction.
- (4) Press OD of gasket (20) into groove by progressively pressing around OD with a suitable tool such as a small screw driver modified to remove sharp corners at its tip.
- (5) Check fit of flapper to gasket in a darkened room by shining a light beam parallel to the plane of the gasket face. Correct any gap by "wringing" gasket face against a flat smooth surface.

C. Installing Locking Mechanism

- (1) Assemble new O-ring (120) to plunger (90) if O-ring requires replacement. Grind outside diameter of O-ring (120) to produce slip fit in locking device hole as described in Repair 3.
- (2) Install pin (110) through hole in plunger. Center pin and orient flats to face interior of body.
- (3) Insert two compression springs (100) into body locking device.
- (4) Insert plunger (90) and pin (110) into body locking part from interior, threaded end inserted first. Assure flats on pin face interior of body.
- (5) Insert block (80) into body locking port from exterior, small countersink first while restraining plunger (90) from being pushed into interior of body.
- (6) Install socket-head cap screw (70) through block and engage and tighten into plunger (90).
- (7) Weld socket-head cap screw (70) to block (80) with a small tungsten arc tack weld using 18-8 SS weld wire. Confine weld to small spot at socket OD. Avoid weld protrusion into hexagonal socket.

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

4. Storage After Assembly

- A. Enclose the unit in a polyethylene bag and place in a suitable cardboard box.

**PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01**

INTENTIONALLY LEFT BLANK

**79-20-03
PAGE 30
MAY 25, 1994**

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

SPECIAL TOOLS FIXTURES AND EQUIPMENT

1. The following table lists the special tools and equipment required for complete maintenance of the unit.

NOTE: Equivalent substitutes may be used for listed items.

Tool Item No.	Tool Part No.	Description	Remarks
1.	091PT071	Pressure Test Fixture	For leak testing flapper seal.
2.	MS9388-331	Pressure Vessel O-ring	For installation on unit during pressure testing.
3.	Pratt & Whitney 478843	Oil cap	For leak testing cap-to- unit interface.
4.	MS9388-331	Oil cap O-ring	For cap leak test.

**PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01**

INTENTIONALLY LEFT BLANK

79-20-03
PAGE 32
MAY 25, 1994

ILLUSTRATED PARTS LIST

INTRODUCTION

1. Purpose

This section provides illustrations and parts breakdown of all parts of the assembly(ies) shown on the title page which can be disassembled, repaired or replaced and reassembled.

2. Explanation and Usage of Section

- A. FIG. ITEM (Figure and Item Number) Column. Item numbers may be prefixed by a hyphen, be suffixed by a letter, or be a combination of both (-10, 10A, -10B). The hyphen prefix indicates that a part is not illustrated in the exploded view. The letter suffix is a variant that indicates an item is similar to the item preceding it.
- B. PART NUMBER Column. This column lists PTC, vendor, and government standard part numbers. A series of letters in the column indicate nonprocurable subassemblies not having a part number. The last part listed in a series of similar parts is the most recent part.
- C. AIRLINE PART NUMBER Column. This column is left blank for airline use.
- D. NOMENCLATURE Column. This column identifies items by the manufacturer's drawing nomenclature. Additional modifiers and/or dimensions may also be included. The vendor codes (five numbers or letters preceded by an uppercase V) or a service bulletin number (prefixed by the uppercase letters SB).
- E. EFF CODE column. Reference letters (A, B, C, etc.) are assigned in the EFF CODE column to each top assembly. The reference letter of the applicable top assembly is also shown in the EFF CODE column for each detail part and subassembly except that no reference letter is shown for detail parts and subassemblies used on all top assemblies.

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01


F. UNITS PER ASSEMBLY column. This column shows the total number of units required per assembly, per subassembly, and per subassembly as applicable. For bulk items, the letters AR indicate "as required". The letters RF indicate the item is listed for reference purposes.

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

VENDOR CODES

Vendor Code	Vendor Name and Address
77445	Pratt and Whitney Canada 1000, Marie-Victorin Longueuil, Quebec Canada J4G1A1
74197	Associated Spring 18 Main Street Bristol, CT 06010

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01



Oil Tank Cap Safety Adapter
Figure 1 - IPL

PTM INTERNATIONAL, INC.
 COMPONENT MAINTENANCE MANUAL
 PT8611A01

FIG. ITEM	PART NUMBER	AIRLINE PART NO.	NOMENCLATURE	EFF CODE	UNIT PER ASSY
1	PT8611A01		Oil Tank Cap Safety Adapter		1
10	MS9388-331		O-Ring		1
20	PT8611-16		Gasket		1
30	PT8611-15		Hinge Pin		1
40	PT8611-5		Flapper Hinge Assy.		1
50	PT8611-9		Screw		1
60	PT8611-20		Lock Clip		1
70	MS1699S-1		Socket-head Screw		1
80	PT8611-8		Block		1
90	PT8611-11		Plunger		1
100	C0088-012-0620M		Compression Spring		2
110	PT8611-12		Plunger Pin		1
120	MS9388-006 (modified)		O-Ring		1
130	PT8611-1		Valve Body		1

PTM INTERNATIONAL, INC.
COMPONENT MAINTENANCE MANUAL
PT8611A01

INTENTIONALLY LEFT BLANK

79-20-03
PAGE 38
MAY 25, 1994