



7447 N. St. Louis Avenue
 Skokie, IL 60076
 www.Primeair.com
 Phone: 847-583-1300
 Fax: 847-675-6346

PART NUMBER	DESCRIPTION	AIRCRAFT TYPE
2606672-4	BRAKE	737
3617750-1	TURBINE TYPE FUEL CONTROL UNIT	737
7147M10G04	POWER MANAGEMENT COMP	737
G7490-40	PANEL	737
3-1479-2	MAIN WHEEL	747
430101	CONTROLLER	757
2-1617	BRAKE	757
273N2004-6	ACTUATOR	757
28823-9	COMPRESSOR	757
335-009-306-0	SPOOL	757
4077880-908	DISPLAY UNIT	757
6678	DETECTOR	757
774984-3	STARTER	757
774987-1	VALVE AIR STARTER	757
898867-3	FIRE EXT IN AFT CARG	757
AHA1884	BRAKE	757
2612412-1A	BRAKE	767
3275538-3	ACTUATOR END	767
5A3294-4	ESCAPE SLIDE	767
692D100-13	ROTARY ACTUATOR	767
692D100-15	ROTARY ACTUATOR	767
729184E	IDG	767
774860A10	STARTER	767
774860A4	STARTER	767
775550-3	STARTER	767
811390-3	STARTER VALVE	767
C20508000	BRAKE ASSEMBLY	767
D2070-3	ACTUATOR	767
1701768	GENERATOR	777
1606130-001	CONTROL-CABLE	777
1U1509-5	SYNC-LOCK MANUAL DRIVE ASSEMBLY	777
2341590-1	CONVERTOR	777
2611202-2	BRAKE	777
3-1535	NOSE WHEEL	777
3-1540	MAIN WHEEL	777
3215302-4	VALVE	777
3290770-6	VALVE	777
3505788-8	STARTER	777

3800550-1	APU	777
4088240-901	DISPLAY UNIT	777
4100941C	FAN	777
5701-1-1	AUDIO SELECT	777
66132-04	HYDRAULIC PUMP	777
756589A	GENERATOR	777
767146A	IDG	777
810208-117	HEAT EXCHANGER	777
810502-3	ANTI-ICE VALVE	777
822-0006-103	COMPUTER, AFDC	777
822-0407-101	ACTUATOR BACKDRIVE	777
822-0409-201	STANDBY ALTITUDE IND	777
90-0408-10	MOTOR	777
TLS755-01-5101A	RECEIVER	777
3840160-8	1ST STAGE TURBINE ROTOR	131-9A
9810	FAUCET ASSEMBLY	737NG
849589	HYDRAULIC PUMP	737NG
0123FA2	SENSOR	737NG
066-50007-0101	RADIO ALTIMETER	737NG
066-50007-0111	RADIO ALTIMETER	737NG
0861FL1	SENSOR	737NG
10037-0770	INDICATOR	737NG
14330-230	VALVE	737NG
1588M89G03	SPOOL	737NG
160564-2	COOLER	737NG
1721F4	SENSOR	737NG
1742F9	SENSOR	737NG
18-1738-10	TRANSMITTER	737NG
2041683-7507	ADF ANTENNA	737NG
2042M67P04	ELECTRONIC CONTROL UNIT	737NG
21933-01AC	CABIN PRESSURE CONTROLLER	737NG
241-280-053-013	VIBRATION MONITOR	737NG
28823-7	COMPRESSOR	737NG
315A2801-1	ACTUATOR	737NG
3215618-4	VALVE	737NG
3289562-6	VALVE	737NG
3800702-1	APU	737NG
3886188-3	VANE ACTUATOR	737NG
3888058-5	EXCITER	737NG
396608-1	VALVE	737NG
4086850-922	DISPLAY UNIT	737NG
4091900-932	DISPLAY UNIT	737NG
4101054	FAN	737NG
42-935-2	ANTI-SKID CONTROL	737NG

441921-5	CONTROL	737NG
473957-4	BOTTLE	737NG
5145-1-77	AUDIO PANEL	737NG
5145-1-82	PANEL	737NG
5A3307-7	SLIDE AY	737NG
7121-19971-01AC	CONTROLLER	737NG
7123-19973-03AB	PRESSURE SELECTOR	737NG
71404-1	VALVE	737NG
72184012b	BOILER	737NG
761574B	IDG	737NG
822-0987-003	HF ANTENNA COUPLER	737NG
822-1710-001	TRANSCEIVER WRT-2100	737NG
902018-01	DETECTOR	737NG
930-1000-001	RADAR PROCESSOR	737NG
930-2000-001	TRANSMITTER/RECEIVER	737NG
940-0351-001	TRAFFIC COMPUTER	737NG
964-0453-011	COUPLER	737NG
965-1690-055	EGPWS	737NG
980-4750-001	HFR5-SSFDR	737NG
980-4750-009	SOLID ST.FLIGHT DATA REC	737NG
980-6022-001	CVR-COCKPIT VOICE RECORDER	737NG
C16221KA02	ISFD	737NG
C16221MA01	ISFD	737NG
C16786HA02	INDICATOR	737NG
G7501-01	NAV MMR,VHF - MULTI MODE RECEIVER,	737NG
HG2050AC07	A.D.I.R.U.	737NG
C5116-11	STARTER	747-400
154ED	SENSOR PROBE-PT2/TT2	A310
418-06124	PRESSURE TRANSMITTER	A310
C13093AA01	ENGINE INTERFACE UNIT	A318
C19266EA01	MCDU-MULTIPURPOSE	A318
C19755BA01	ENHANCED DISPLAY UNIT	A318
C16786EA01	ISIS	A319
772292	IDG	A320
066-50007-0212	RADIO ALTIMETER	A320
144-405-000-033	SENSOR	A320
154DB3	PROBE/SENSOR	A320
2056C0000-01	PLENUM	A320
20790-03AC	VALVE-OUTFLOW	A320
3-1530	MAIN WHEEL	A320
3291556-3	START VALVE	A320
329695-4	VALVE	A320
3505582-27	STARTER	A320
3505582-65	STARTER	A320

3800708-1	APU	A320
3876227-2	SENSOR	A320
4101002-11	TRANSFER UNIT-HYD POWER	A320
6237M99C	TRF SENSOR	A320
753C0000-02	EXCHANGER-HEAT,PRIMARY	A320
790425A4	STARTER	A320
790425A6	STARTER	A320
940-0300-001	COMPUTER	A320
974540	PUMP-ELECTRIC	A320
C12850AC02	FCU-FLIGHT CONTROL UNIT	A320
C13042BA03	COMPUTER-FLT MGT	A320
C13043AA03	FLIGHT MANAGEMENT AND GUIDE	A320
C19298AF05	DISPLAY UNIT	A320
C20195162	WHEEL	A320
C20225510	BRAKE ASSY	A320
C25175000-2	VALVE	A320
HG2030AE22	A.D.I.R.U.	A320
E21327106	BSCU	A320
EVR750-04-0100A	TRANSCEIVER-VHF	A320
VFT210B00	VALVE-SKIN AIR	A320
VFT300B00	VALVE-SKIN AIR	A320
C20534000-1	BRAKE	A321
974976	HYDRAULIC PUMP	A330
3022053-001	PUMP-HYDRAULIC	A330
3-1546	MAIN WHEEL	A330
3888217-4	APU STARTER	A330
6763D080000	BLEED VALVE	A330
735632-7	HYDRAULIC SYSTEM MONITORING	A330
752168B	IDG-INTEGRATED DRIVE GENERATOR	A330
B494AAM0617	FCMC (FUEL CONTROL MONITOR CPTR)	A330
C12858BA02	FLIGHT MANAGEMENT COMPUTER	A330
C13039CA01	FMGEC (FLIGHT MANAG GUID ENV COMP)	A330
C13164HA02	FLIGHT MANAGEMENT	A330
C143620-2	CHECK VALVE	A330
C145531-3	ANTI-ICE VALVE	A330
J540AI4-100	GENERATOR	A330
LA2K2B100DF0000	FLIGHT CONTROL PRIMARY COMPUTER	A330
3-1518-2	MAIN WHEEL	ATR42
2340356-3	HEAT EXCHANGER	ATR72
815470-2	HUB-6 BLADE	ATR72
815585-7	PROP ACTUATOR	ATR72
82425-00-0060	NAVIGATION UNIT	ATR72
AHA1653	BRAKE	ATR72
R815505-6	PROPELLAR BLADE	ATR72

SFA13S1P0A	PROP BLADE	ATR72
822-1821-330	MULTI MODE RECEIVER	B737N
AHA2331-4	BRAKE	BAE146
AHA2332-2	BRAKE	BAE146
418-17054	PRESSURE TRANSMITTER	CF6-80C
329695-5	VALVE	CFM56
1475M29P03	DISK	CFM56-3
2084M33P02	BLADE	CFM56-3
C13045CA02	SPOILER & STABILIZER CONTROL	CRJ
C16221AA02	INDICATOR, INTEGRATED STAND	CRJ
778683-2	HEAT EXCHANGER	DASH 8
C12432AA06	INPUT/OUTPUT PROCESSOR MODULE	DASH 8
5000758-10R	BRAKE	DC10
7U7941-5	LOCKING ACTUATOR(RIGHT LOWER)	EJET
AHO91427	HEAT PACK	G-V
AHM9029	ROTOR SEGMENT	HAWKER
AHO83829-9	PAD	HAWKER
154ED2	SENSOR	MD11
2609472-4	BRAKE	MD11
28B528-2	APU GENERATOR	MD90
066-01143-2101	RECEIVER, ATC	Q400
066-01146-1211	PROCESSOR, TCAS II, W/CHG 7	Q400
1152106-3	STARTER GENERATOR	Q400
1406-01-1	DATA TRANSFER	Q400
3-1480-2	MAIN WHEEL	Q400
390500-1011	RUBBER PCU	Q400
51149-04	UNIT, POWER TRANSFER	Q400
96042-08	ISOLATOR	Q400
C12424AE	PANEL	Q400
LA11A2104	ACTUATOR	Q400
47385	POWER CONDITION CONTROL	RB211-535
763569-6	STARTER	RB211-535
071-50013-0100	ANTENNA	TCAS
822-1293-002	TCAS PROCESSOR	TCAS
822-1293-322	COMPUTER-TCAS	TCAS
9000000-11111	TCAS PROCESSOR	TCAS
9000000-20004	TCAS PROCESSOR	TCAS
9000000-20005	TCAS PROCESSOR	TCAS
9005000-10101	TCAS PROCESSOR	TCAS
822-0101-002	RECEIVER	VAR